22

Enumerations

Introducing Enumerations

- > Enumeration is a collection of constants.
- > Enumeration is used to specify the list of options allowed to be stored in a field / variable.
- Use enumeration if you don't want to allow other developers to assign other value into a field / variable, other than the list of values specified in the enumeration
- > Accessing Member: EnumerationName.ConstantName

```
enum EnumerationName
{
    Constant1, Constant2, ...
}
```

By default, each constant will be assigned to a number, starts from zero; however you can change the number (integer only).

```
enum EnumerationName
{
    Constant1 = value, Constant2 = value, ...
}
```

> The default data type of enum member is "int". However, you can change its data type as follows.

```
enum EnumerationName: datatype
{
    Constant1 = value, Constant2 = value, ...
}
```

